

# CONNECTING SOLAR PANELS

4000 RIGID KIT

200 watt panel

**ONLY FOR POINT ZERO ENERGY SOLAR PANELS.  
DO NOT USE this wiring diagram with any other solar panels.**

- A- Titan Boost Power Module
- B- Titan 2000 wh battery pack
- C- Anderson to MC4 adapter
- D- MC4 extension cable
- E- Branch connector
- F- 15 ft. MC4 extension cable
- G- 200 watt rigid solar panels

